



- [Input side terminal]                      [Output side terminal]
- ① :Input Terminal                      ③ :Output Terminal
  - ② :Input Terminal                      ④ :Output Terminal
  - FG :Ground Terminal \*1              BP :Ground Terminal \*2

\*1 Connect to ground  
 \*2 Connect to baseplate of power modules

(unit : mm)

MODEL NAME	PAN4820
<b>TDK-Lambda</b>	
G041-02-01E	