



Parts Selection Tool TDK Meister

How to install

TDK Corporation
Electronic Components Business Company
Marketing Strategy Group
Products & Application Collaboration
March 25, 2024

Contents

1 System Requirements

2 Installation

3 Uninstallation

1 System Requirements

This page outlines the minimum system requirements you need to run TDK Meister.

- OS : Windows 10, Windows 11
- Microsoft .net framework : ver. 4.7.2 or higher
- Disk Space : 1.1GB or more (Installer 300MB + Program Folder 800MB)

2 Installation

To install TDK Meister, please execute the following procedure.

1) Unzip the installer zip.



tdk_meister_installer.zip


2) Save the program folder that appears after unzip the installer zip at any directory of your PC.

unzip



TDKMeister_2024.03

save at any directory of your PC



Make a shortcut if needed.



TDKMeister.exe - Shortcut

3) Delete the install zip.



delete



tdk_meister_installer.zip

Recycle Bin

- The execute file is "TDKMeister.exe" in the program folder. It's convenient to create a shortcut of this file on desktop.
- If TDK Meister is installed in a directory on network drive, program may not work properly. In this case, please install local directory of your PC.

3 Uninstallation

To uninstall TDK Meister, please execute the following procedure.

1) Delete the program folder and shortcuts.

